

SAA09FY12-006  
REV. BB/L: 389.00  
SYS: 175-TON  
BRIDGE  
CRANE, VAB

AUG 20 1993

Critical Item: Relay, Aux Hoist (2 total)  
 Find Number: HCR RUN, LCR RUN (1 ea)  
 Criticality Category: 2

SAA No:	09FY12-006	System/Area:	175-Ton Bridge Crane/VAB
NASA		PMN/	K50-0528/
Part No:	NA	Name:	175-Ton Bridge Crane/VAB
Mfg/	Cutler Hammer/	Drawing/	67-K-L-11348/
Part No:	9575H2068A Model:6-2-3	Sheet No:	17

Function: Controls relay 2RUN for energizing the generator field winding during hoisting, lowering or float operations.

**Critical Failure Mode/Failure Mode No:**

- a. Coil fails open/
  - 09FY12-006.041 (HCR RUN)
  - 09FY12-006.044 (LCR RUN)
- b. N.O. contact fails open/
  - 09FY12-006.042 (HCR RUN)
  - 09FY12-006.045 (LCR RUN)
- c. N.C. contact fails closed/
  - 09FY12-006.043 (HCR RUN)
  - 09FY12-006.046 (LCR RUN)

**Failure Cause:**

- a. Corrosion, fatigue
- b. Corrosion, binding mechanism.
- c. Welded contacts, binding mechanism.

Failure Effect: (For all three failures) Relay 2RUN N.O. contact will not close and generator field winding will not be energized. No output from the generator. No hoist motor torque while the command is being given to raise, lower or float the load and the brakes are released. The load will descend with regenerative braking at 1.7 ft/min (0.34 in/sec) max (based on maximum load capacity of the hoist, in reality this would descend slower). The worst case would be attempting to lift or float a forward assembly from the stop position.

releasing the brakes, the failure occurring, and the effect being the forward assembly descending and striking the VAB floor or platform, resulting in possible damage to a vehicle system. Time to effect: seconds.

### ACCEPTANCE RATIONALE

#### Design:

<u>Contact Ratings</u>	<u>Actual</u>
600 volts	120 volts
10 amps	Testing required
<u>Coil Ratings</u>	<u>Actual</u>
120 volts	120 volts

- Contacts - Weld resistant, dome shaped, self wiping, silver cadmium oxide, double break operation.
- Coils - Bobbin wound coils are varnish impregnated under vacuum to prevent corrosion due to moisture.
- Armature - Balanced armature to minimize bounce for maximum contact life.
- Shock and vibration resistant construction.
- This relay was off-the-shelf hardware selected by the crane manufacturer for this application.

#### Test:

- OMRSD file VI requires verification of proper performance of hoist operational test annually.
- OMI Q3008, Operating Instructions, requires all crane systems be operated briefly in all speeds to verify satisfactory operation before lifting operations.

#### Inspection:

- OMI Q6003, Maintenance Instructions, requires annual inspection of relay contacts and contact members for burning, pitting, proper alignment, and discoloration caused by overheating; visual check of closing coils for deteriorated insulation and evidence of overheating or burning.

#### Failure History:

- The PRACA database was researched and no failure data was found on this component in the critical failure mode.
- The GIDEP failure data interchange system was researched and no failure data was found on this component in the critical failure mode.

AUG 20 1993

**Operational Use:**

• **Correcting Action:**

- 1) The failure can be recognized via the Selsyn (positions change) that is in view of both operators.
- 2) When the failure indication is noticed, the operator can stop all crane operations by returning the Master Control Switch to neutral or pressing the E-Stop button (releasing the brake switch in the float mode).
- 3) Operators are trained and certified to operate these cranes and know and understand what to do if a failure indication is present.
- 4) During all critical lifts, there is at least one Emergency Stop (E-Stop) operator remote from the operator's cab observing the load lift, and can stop the crane if a failure indication is noticed.

• **Timeframe:**

- Estimated operator reaction time is 3 to 10 seconds.